

Parameters Casio HT-3000 / HT-700

Upper Tone	Lower Tone		
00 dco wave	30 dco wave		
01 lfo depht	31 lfo depht		
02 lfo wave			
03 lfo delay			
04 lfo speed			
10 cut off	40 cut off		
11 resonance	41 resonance		
12 vcf attack	42 vcf attack		
13 vcf decay	43 vcf decay		
14 vcf sustain	44 vcf sustain		
15 vcf release	45 vcf release		
16 vcf env depth	46 vcf env depth		
20 dca attack	50 dca attack		
21 dca decay	51 dca decay		
22 dca sustain	52 dca sustain		
23 dca release	53 dca release		
24 dca env depth	54 dca env depth		
60 chorus			